




Replacing the Handle Grip



1. Remove worn grip: Remove worn or damaged handle by carefully cutting or slicing its end.



2. Remove worn handle: Remove worn handle and dispose of it.



3. Install new grip: Replace the grip by sliding onto the handle. May require lubricant.

IMPORTANT: Before performing any repairs to the unit, be sure that the power source is disconnected.

Tools Required: Scissors



For more information, contact the Clorox Total 360 Support Team.
U.S.A.: 866-397-8360
Canada: 877-694-7360
Service@CloroxTotal360Support.com
www.CloroxTotal360Support.com

© 2022 Clorox Professional Products Company,
1221 Broadway, Oakland, CA 94612.

NI-57433