## 🔒 TECHNICAL & SAFETY INFO

### **CLOROXPRO**

# **Packaging Instructions: Clorox® Total 360® ProPack**





For more information, contact the Clorox Total 360 Support Team. U.S.A.: 866-397-8360 Canada: 877-694-7360 Service@CloroxTotal360Support.com www.CloroxTotal360Support.com

© 2022 Clorox Professional Products Company, 1221 Broadway, Oakland, CA 94612.



- 1. What's included You will be shipped:
  - Box #1 (box that it comes in can be recycled): Inside, there will be a flattened box with a pre-paid shipping label already adhered.
  - Box #2 (box can be recycled): Packaging instructions
    - a. 1 foam floor
    - b. 1 foam top
    - $\ensuremath{\textbf{c.}}\xspace1$  wand foam pocket



2. Remove existing bottles Place device on steady flat surface, remove bottles and spray remaining liquid in the system.



**4. Insert the foam floor (part A)** Drop the foam floor plate with the large pockets that matches the bottom of your device.


**Pro Tip:** Follow the orientation of the images to ensure proper fit.



3. Create the shipping box

Fold the flat box (Box #1) into a square shape and apply packing tape to the bottom of the box. Start the packing tape at least halfway down the side of the box, then bring it across the bottom and down the other side. Make sure to go at least halfway down the side of the box with tape. Press the tape on the box for good adhesion and apply several layers if desired.

NI-56733



5. Insert wand into foam pocket (part C)

Insert the wand into the foam pocket. Orient so that the slit at the bottom allows the handle to fit into place.



6. Insert device into box

**a.** Place device in the box. Line up and match the device shape & orientation to the pocket shape on the foam floor plate inside the box.

**b.** Wrap the spray wand around the device and set the wand with the foam pocket into foam floor.

 $\ensuremath{\textbf{c}}.$  Wind up the extension cord and place inside device where the bottle sits.

d. Place the holster in the box to the left side of the device.



7. Insert foam top (part B) Drop foam top plate into place over the handle of the device.

**Pro Tip:** The side with the cut-out edge should be closest to you.



### 8. Close the box

Fold the short flaps over. Then, fold the long flaps down to close the box and apply packing tape to the seam. Start the tape at least halfway down the side of the box, then bring it across the top and down the other side. Go halfway down the side of the box with tape. Press the tape on the box for good adhesion and apply several layers if desired.

#### 9. Ship your device

A prepaid shipping label is on your box. Drop off the box at your nearest UPS location.